Connector Installation Instruction for 1-1/4”R leaky RF cable short type

Please read the instruction carefully before installation. Any improper operation can result in badness influence and sequel.

Installation tools: Saw, Utility Knife, Wrench, Diagonal Pliers and so on.

Series	N	7/16	4.3/10
Suitable connector type	NM-1-1/4” R NF -1-1/4” R	7/16M-1-1/4” R 7/16F -1-1/4” R	4.3/10M-1-1/4” R 4.3/10F -1-1/4” R

（the specific installation steps as shown in the figures）:



1. Use the saw to cut the cable.



2. The surface should be plane and clean.



3. Peel the leaky cable mark line at least 35mm.



4. Cut around the jacket of the cable 8mm.



5. Use the diagonal pliers to strip the jacket of the cable.



6.Fix back DOS Shell on cable.



7. Set into the cable clamp Ensure that the end face of the cable is flush with the cable clamp.



8.Flaring.



9. Keep main shell body stopped, turn back DOS shell to tighten main shell body.



10. Assembling is finished.